Clarke®

Ultra Speed Burnisher

120V & 240V with NEMA Plug



Operator's Manual
Manual del operador
Manuel de l'utilisateur

READ THIS BOOK — EN English (2 - 12)

LEA ESTE MANUAL — ES Español (14 - 24)

LISEZ CE MANUEL — FR Français (26 - 36)

This book has important information for the use and safe operation of this machine. Failure to read this book prior to operating or attempting any service or maintenance procedure to your Clarke American Sanders machine could result in injury to you or to other personnel; damage to the machine or to other property could occur as well. You must have training in the operation of this machine before using it. If your operator(s) cannot read this manual, have it explained fully before attempting to operate this machine.

All directions given in this book are as seen from the operator's position at the rear of the machine.

For new books write to: Clarke®, 2100 Highway 265, Springdale, Arkansas 72764